

Callidus 8 port UHF RFID reader

(v1.0)

INSTALLATION AND SERVICE GUIDE



Version 1.0
01 August 2021



C8P UHF RDR 8 PORT RFID READER GEN2 FEATURES

- RFID tag reading, inventorying and editing
- People counting
- Additional alarm outputs
- Additional binary inputs
- Additional binary outputs
- Smarter way of RFID detection inside AM TRX or RF TRX pedestal and even outside the pedestal
- Easy installation and setup
- External and internal alarm actions
- And much more...

REFERENCE MANUAL

CONTENT

1. Operation guidelines..... 3

2. Basic information..... 3

3. Pre-install tasks 3

 3.1 C8P UHF RDR system placement..... 3

 3.2 Installation equipment for C8P UHF RDR system 3

4. Specifications..... 4

 4.1 UHF RFID..... 4

 4.2 Power..... 4

 4.3 Connectivity..... 4

 4.4 User interface..... 4

 4.5 Software interface 4

 4.6 Mechanical specifications 4

 4.7 Environmental..... 4

5. C8P UHF RDR ports 5

6. Setting connection and software description..... 6

 6.1 Connecting to the PC/Laptop..... 6

 6.2 Login details 6

 6.3 Software description 6

 6.4 People counting..... 7

 6.5 Alarms.....10

7. Mounting C8P UHF RDR system – general recommendation.....10

 7.1 Reader installation and placement10

 7.2 Reader cable and wiring.....10

8. REST API Implementation10

 8.1 Advantages of REST API10

 8.2 Quick test examples.....10

9. Declaration.....10

 9.1 Equipment modification caution.....10

 9.2 Limitation of liability.....10

10. Notes.....10

LIST OF PICTURES

Figure 1 Device discovery software - eComm Discoverer.....	6
Figure 2 Login page.....	6
Figure 3 Networking – Group ID and Pedestal ID.....	7
Figure 4 Main screen of PeopleCounter - PeopleCounter not in use	8
Figure 5 PeopleCounter screen - none signal from TX sensor.....	8
Figure 6 PeopleCounter screen - visible signals from TX sensor	9
Figure 7 People counting on RFID – settings for external PC.....	9
Figure 8 People counting on RFID – settings for internal PC.....	10
Figure 9 Installation example of 2 pedestals with AM TRX or RF TRX	10
Figure 10 Installation example of 3 pedestals with AM TRX or RF TRX.....	10
Figure 11 Example in PowerShell (Windows).....	10
Figure 12 Example in Bash (Linux).....	10

1. OPERATION GUIDELINES



CAUTION! Before operating this device, all operating technicians should study this manual and device technical data to understand and follow the safety instructions. Keep these instructions with the device for further reference. If you have any questions, contact your device representative or distributor.

This is a Class A product. In a domestic environment, this product may cause high-frequency interference. In this case, it may require the user to take appropriate precautions.

2. BASIC INFORMATION

- The “C8P UHF RDR” is an eight-port UHF RFID reader with Ethernet, USB and GPIO connectivity
- The local user interface consists of two LEDs (for Reader and RFID status), one internal button and internal buzzer
- Reader has also 2 connectors for people counters, connector for light and external buzzer used for alarm indication
- The reader allows power over ethernet or external adapter
- All configuration parameters and device functionality can be controlled with browser via webserver or with customized software that communicate with reader via REST API

3. PRE-INSTALL TASKS

3.1 C8P UHF RDR system placement

- Inside the compactible AM TRX or RF TRX pedestal
- Outside the pedestal on the ceilings, walls, etc.

3.2 Installation equipment for C8P UHF RDR system

- 1x C8P UHF reader GEN2
- 1x compatible pedestal with RFID antenna (inside installation)
- 1x LAN cable (with PoE)
- 2x coaxial cables with SMA connectors (if used multiple antennas)
- 1x external power supply if used without PoE
- Laptop with browser (Google Chrome recommended)

4. SPECIFICATIONS

4.1 UHF RFID

Operating frequency US version	902 - 928 MHz
Operating frequency EU version	865,6 - 867,6 MHz
RFID protocol support	GEN2
Reading speed	Up to 750 tags/sec
Reading distance	Up to 5 m (depending on multiple factors as position, presence of metals or objects filled with liquid, used tags, antenna gain and more)
Transmit power	Adjustable from -10 dBm to +30 dBm in 1 dBm steps

4.2 Power

Power over Ethernet	PoE 802.3 af
Or external adapter	100-240VAC to 48V/0.5A
Power consumption	max. 12 W

4.3 Connectivity

UHF RFID antenna	8x SMA female / 50Ω
LAN	10/100Mbit Ethernet, IPv4 DHCP or static IP
USB	1x USB B
People counter	2x RJ45 6pin connector for IR sensors
Alarm optical indicator	1x RJ45 4pin connector for RGB LED
Alarm sound indicator	1x 2pin connector for external buzzer
Binary input	2x opto-isolated max. 30V DC
Binary output	2x opto-isolated max. 60V/0,5A DC

4.4 User interface

Optical indicators	2x RGB LED
Sound indicator	Internal buzzer
Button	Reset to factory default button

4.5 Software interface

RFID API	Callidus REST API
-----------------	-------------------


4.6 Mechanical specifications

Height	89 mm
Width	175 mm
Depth	26 mm
Weight	0,25 kg

4.7 Environmental

Ambient temperature	0 - 35 °C (equipment for normal indoor use)
Relative humidity	0 - 90 % (non-condensing)

5. C8P UHF RDR PORTS



1. **Antenna ports** – 8x SMA female connectors for antennas
2. **Factory reset** – button, hold for 10 s to reset all settings to factory default (including networking configuration)
3. **Reader status** – LED indicating status of reader
4. **RFID status** – LED indicating status of RFID module
5. **DC IN 48V** – input voltage (external power supply)
6. **LAN+PoE IN** – data communication with PoE
7. **LAN only** – data communication only
8. **USB** – currently not used
9. **People counter** – input for people counter IR sensors
10. **GPIO** – universal binary input and output (opto-isolated)
11. **Light** – optical signaling output (RGB light)
12. **Sound** – alarm output of acoustic signaling (piezo)

Table 1 LED "Reader status" colors and their meaning

Glows blue	Device is powered up, but does not have IP address.
Glows orange	Device has IP address and no client is connected.
Glows green	Client is connected.
Flashes orange	Device is in bootloader mode and waiting for new firmware to be uploaded.
Glows white	Device is in bootloader mode and uploading new firmware.
Flashes green	New firmware has been uploaded.

Table 2 LED "RFID status" colors and their meaning

Glows green	RFID reading is ON.
Glows orange	RFID is currently writing.

6. SETTING CONNECTION AND SOFTWARE DESCRIPTION

6.1 Connecting to the PC/Laptop

- The device can be powered by ethernet cable itself if the network supports PoE feature or else DC 48V/0.5A external power adapter must be used.
- The ethernet cable must be connected with the device and the PC/Laptop in the same ethernet network.
- Then the device has to be discovered. RFID reader is very simple to find. Just open up “eComm Discoverer” and search for name “C8PURDR”. Then just double click on that row and new window with login should appear.




Figure 1 Device discovery software - eComm Discoverer




Figure 2 Login page

6.2 Login details

Username for user with limited rights: **user**
Default password: Call + last 6 numbers of MAC
Example for MAC '1A:2B:3C:4D:5E:6F': Call4D5E6F

Username for admin with full rights: **admin**
Default password: Call + last 6 numbers of MAC with reverted double digits
Example for MAC '1A:2B:3C:4D:5E:6F': CallD4E5F6

6.3 Software description

After successful login as admin, Dashboard page should appear. On the left side is menu consisting of 11 tabs:

1. **Dashboard** – basic information about reader such as device and system statuses, tags memory etc.
2. **Tags** – list of saved tags, reading statistics, start/stop inventorying
3. **Edit tags** – used for editing access or kill password, EPC, user memory, tag locks or simply for inspection of all banks
4. **RFID** – all settings about RFID like region, power, antenna ports, hop table, protocols and filters
5. **People counting** – PC settings, status and counters if internal PC used
6. **Alarms** – alarm indication settings
7. **GPIO** – input and output configuration
8. **Date & time** – time synchronization and time zone offset settings
9. **Networking**
10. **Firmware update**
11. **Factory reset**


6.4 People counting



CAUTION! The People Counter (PC) is only available if at least two or more pedestals are installed. A prerequisite for proper PC operation is that all pedestals are installed in the same direction.

People counting can be done with 2 possible ways, depending if RFID reader is working alone or with AM/RF TRX system:

- RFID reader works alone without AM/RF TRX system, people counting and direction determination is done with RFID reader and IR sensors are connected to RFID reader input labeled “People counter”.
- RFID reader works with AM/RF system. Typically, both boards are in the same pedestal and IR sensors are connected to AM/RF board input labeled “People count”. People counting is then handled by AM/RF system and shared with RFID via local networking for tags direction determination.



PC setup for AM TRX or RF TRX with RFID

PC sensors are connected to AM/RF TRX electronic board. RFID reader and AM/RF TRX electronic board have to be in the same network. Group ID and Pedestal ID have to be set correctly in the Networking folder.

The standard installation is when, from the side view of the antennas, the Master antenna is the left most one (Pedestal ID 0) and other Slave pedestals are placed to the right (Pedestal ID 1 – n). This arrangement makes it easier for us to check the correct PC settings.

The screenshot shows a web interface for configuring networking settings. The 'Pedestal BUS settings' section is highlighted with a red box, showing 'Group ID' set to 1 and 'Pedestal ID' set to 0. Other sections include Networking status, IP settings, Cloud connection, Actions, MQTT IOT, and Web API access.

Figure 3 Networking – Group ID and Pedestal ID

At first, we will set the Master antenna, due to the following one, works as Transmitter or Receiver (it can be found out in the documentation of the particular antenna type how the transmitting or receiving diodes of the PC system are oriented due to placement of electronic boards).




Figure 4 Main screen of PeopleCounter - PeopleCounter not in use

If, in our example, the master is set so that the following antenna is a receiver, after selecting the Counting mode – Receiver, the screen looks like this:




Figure 5 PeopleCounter screen - none signal from TX sensor

Red LEDs indicate that the transmitter does not lit to the receiving sensors. The SlavesAutoConfiguration option automatically selects all the following Slave antennas to the correct Counting Mode. If no using the Slaves Autoconfiguration option, it is necessary to set each Slave system manually.




Figure 6 PeopleCounter screen - visible signals from TX sensor

If everything is well installed, the LED is green, the status of next antenna can be seen in the Next pedestal window – in this case that the Transmitter is set. Passing through the antenna will shade the sensors, the Sensor stat will blink red and the counter will increment, depending of the direction of passage.

Once the PC is correctly setup on AM/RF TRX it is necessary to setup RFID. In this case sensors are connected to AM/RF TRF electronic board, so on Evaluating sensors External PC is used. Group ID and Pedestal ID has to be same as on Receiver shown on Figure 3. After pressing Save settings all new tags should now have assigned direction from external PC sensors.




Figure 7 People counting on RFID – settings for external PC

PC setup for RFID only

PC sensors are connected to RFID reader. Pedestal 1 is connected to PC1 and set as receiver. Pedestal 2 is connected to PC2 and set as transmitter. LEDs indication have same meaning as before. Red LED indicate that the transmitter does not lit to the receiving sensors, green indicate visible signal from TX and grey means that sensors are disabled.

As before Evaluating settings have to be setup. In this case receiver is on PC1 so Evaluating sensors are set to Internal PC1. After pressing Save settings all new tags should now have assigned direction from internal PC sensors.




Figure 8 People counting on RFID – settings for internal PC

6.5 Alarms

RFID reader has 8 predefined alarms, that are fully customized. Each alarm consists of light and sound indication. Light sequence has 3 steps, where each step has color and duration. Sequence can be repeated. After that it is possible to set delay between alarms and decoration color. Sound indication has also sequence of 3 steps, where each step has ON interval and OFF interval. Just like light can be repeated and delayed between alarms. Each sound alarm can have different volume for internal or external buzzer.

Current version does support stand-alone configuration and alarm can be triggered by reader itself if alarm criteria are met or can be triggered by superior system via API or GPI.

7. MOUNTING C8P UHF RDR SYSTEM – GENERAL RECOMMENDATION

7.1 Reader installation and placement

C8P UHF RDR Reader can be installed inside a pedestal or outside the pedestal like ceiling, cash desk, wall, etc. When the RFID reader is installed within the AM TRX or RF TRX pedestal, it can be used for both RFID and AM/RF tag detection. One reader is fixed inside one pedestal and that can be used for 1 or 2 entrance/s. The reader is placed inside the pedestal, the pedestal can be installed by following the user manual for AM/RF TRX installation and placement. If the reader is placed outside the pedestal, antennas can be placed anywhere like ceiling, cash desk, wall, etc. The antennas are connected to the reader via coaxial cables.

7.2 Reader cable and wiring

For inside AM TRX or RF TRX pedestal:

- In case of using LAN cable with PoE features the reader needs to be wired only with 1x LAN cable and 1-4 coaxial cables with SMA connectors. External power supply will be needed if LAN cable does not have PoE feature.
- RFID antennas are placed inside the pedestal to detect the RFID tags in the entrance. The antennas can be placed in the TOP and BOTTOM of multiple pedestals (2, 3 or more pedestals) to detect RFID tags in the total detection range.
- The AM TRX pedestal wiring details are given in the AM/RF TRX installation and service guide. GPIO interface is connected with a universal output port (ref. AM/RF TRX installation and service guide) in AM/RF TRX el. board




Figure 9 Installation example of 2 pedestals with AM TRX or RF TRX




Figure 10 Installation example of 3 pedestals with AM TRX or RF TRX

For outside AM TRX pedestal:

- In case of using LAN cable with PoE features the reader needs to be wired only with 1x LAN cable and 1-4 coaxial cables with SMA connectors. External power supply will be needed if LAN cable does not have PoE feature
- RFID antennas are placed on the wall, ceiling, cash desk, floor, etc. and connected to the reader via coaxial cables

